

# Accessories for wheelie bins

## Safety Stand for Wheelie Bin

- ▶ Protects the bin from being stolen.
- ▶ If the stand is locked, the lid of the bin cannot be opened.

Type **3025-1** for 120 l

 15 kg

Type **3025-2** for 240 l

 17 kg



## Rubbish Bag Frame



Type **0057** for 120 l (bag: 1077)

Type **0058** for 240 l (bag: 1076)

## Bin Locks



**Chain Lock**

Type **0925**

**Triangle Lock**

Type **2026**

**Gravitational Keyless Lock**

Type **2027-A**

**Gravitational Keyed Lock**

Type **2027-B**

- ▶ To lock, the lid must be closed and locked by a key or handle.

- ▶ The key can be removed when the lid is open; the lid locks when closed.

- ▶ The key can only be removed after closing and locking the lid.